

pole installation information

The information supplied in this document is a generalized description of the installation of the structures supplied by Lyte Poles. It is not a comprehensive guide on how to install these structures. Installation contractors must be relied upon for equipment and practices that meet the conditions of each job location.

Lyte Poles shall not be responsible for any damage that occurs during or after installation, or for any structure that has been modified by the purchaser or is used in some way other than our application recommendations.

grounding & protection against electric shock

- The purchaser and installer must provide electrical groundings and warnings about electrical hazards in accordance with applicable codes

installation guidelines

1. Attach sling to top of pole.
2. Attach luminaries and complete wiring.
3. Place leveling nuts and washers on anchor bolts.
4. Erect pole.
5. Position over anchor bolts and set on leveling nut washers.
6. Place anchor nuts and washers on anchor bolts and tighten once pole is plumb.

direct burial foundations

- Our quotations will reflect a suggested burial depth.
- Soil and site locations will vary, for this reason, it is imperative to consult with a qualified engineer with knowledge of the local soil conditions.
- Lyte Poles cannot be responsible for decisions made regarding the installation, embedded depth or factors related to the specific site location.

anchor bolt foundation

- The concrete foundation must be designed by a qualified engineer with knowledge of the local soil conditions.
- Anchor bolt diameter, length and psi are specifically selected to withstand load limitations listed in the catalog or quote.
- Anchorage supplied by others:
 - » Contact the factory for the correct size and strength.
 - » Lyte Poles will not be held responsible for the structural integrity of the system if anchor bolts are supplied by others.
- The bolt circle template provided conforms to the bolt circle of the pole base.
- When leveling nuts are used, the bottom of the lowest leveling nut shall not be more than 1" from the concrete surface.
 - » Large spaces between the pole base plate and the concrete can cause excessive stresses in the anchor bolts.

NOTE: Do not erect pole without the intended loading attached.

